



TOWERS TANKS

- Water • Molasses • Chemical Tanks
- Roller Lickers & Troughs



FREE
CALL

1800 65 99 46

- STORING THE FRESHEST WATER IN YOUR TANK. WHEN IT RAINS YOU WANT TO MAKE SURE THE NEW WATER COMING IN DOES NOT GO STRAIGHT OUT OF THE OVERFLOW. THE OLDEST WATER IS ALWAYS AT THE BOTTOM OF YOUR TANK. BY CARRYING THE OVERFLOW INTERNALLY TO THE BOTTOM OF YOUR TANK, WHEN IT RAINS THE OLDEST WATER WILL EXIT THROUGH THE OVERFLOW. WHEN AND IF THE OVERFLOW IS CARRIED TO GROUND LEVEL, THE OVERFLOW WILL NEED TO BE VENTED AT THE TOP TO PREVENT SYPHONAGE.



Been 'round for years